
TORK ® Hydraulics

Power Pack Series

THF3 Series Power Packs for lift

Circuit diagram





How to order

THF3	– D2 / 1.6		- G2.0	- SRH4			
Product type	Electric motor		Gear pump	Oil tank			
Appilication	Voltage	Power	Displacement	Material	Section	Mounting	Capacity
Power packs for lift	D1: DC12 D2: DC24	1.6: 1.6KW 2.0: 2.0KW 2.5: 2.5KW	G1.6: 1.6cc/r G2.0: 2.0cc/r G2.5: 2.5cc/r G4.0: 4.0cc/r	S: Steel	R: Round	H: Horizontal V: Vertical	4: 4L 5: 5L 6: 6L 8: 8L

– P21	G24	M	– 4G	
Relief valve	Solo	enoid valve	Oil port	
System pressure	Voltage	Manual override	Thread type & size	
D40, 40MD			4G: BSP 1/4"	
P10: 10MPa	G12: DC12	No code: Standard	6G: BSP 3/8"	
P16: 16MPa	G24: DC24	M: Manual override	4S: SAE 4	
P21: 21MPa			6S: SAE 6	

Remark

Please contact us for special requirements such as different motor power & speed, pump displacement, tank material & capacity or oil port type.

Technical data

DC Motor	Speed (r/m)	2800	
	Rotation	CW	
	Duty	S3	
	Ingress protection	IP54	
Hydraulic fluid		Mineral oil	
Seal material		NBR seals	
Temperature range (°C)		-30 to +80	
Viscosity range (mm ² /s)		2.8 to 500	
Oil cleanlines	Class 20/18/15		

Notes


- 1. The power unit can't work continuously due to S3 duty e.g. 1 min on , 2 min off .
- 2. Clean all hydraulic parts before mounting the power pack.
- 3. First oil changing is after initial 100 hours running time. After that, do oil changing every 3000 hours.

TORK ® Hydraulics

Power Pack Series

THF3 series power pack dimensions

Unit: mm



Tank capacity	4L	5L	6L	8L	10L	12L
L1	225	265	290	385	465	545
L	427	467	500	587	667	747